

ARN5003

ASSEMBLY & INSTALLATION GUIDE

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING * SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Install the crossbar (B) to outlet box by using mounting screws (C) provided.
2. Connect the Ground (bare) fixture wire with the ground (usually bare) wire from your ceiling box using wire nut (A). If your house does not have ground wire, then attach this wire to the green grounding screw inside of outlet box.
3. IT IS IMPERATIVE THAT THE J-BOX IN YOUR HOME BE PROPERLY GROUNDED
4. Connect the Neutral fixture wire with the Neutral (usually white) wire from your ceiling box using wire nut (A).
5. Connect the Hot (smooth edge, markings, or black) fixture wire with the Hot (usually black) wire from your outlet box using wire nut (A). DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED. Tuck these wire connections neatly into canopy (H) to secure.
6. Attach the ceiling loop (D) to the canopy (H) and secure with lock collar (I).
7. Secure the top ring (E) tightly with metal part (G) by locking screws(F).
8. Attach the bottom ring (J) to the chain and secure with screws.
9. Insert light bulbs (not included) into socket.
10. Attach the top shade (K) to the bottom shade (M), and secure tightly with screws (L).
11. Installation is complete.

